













# ▲existents

## FOLDABLE TENT SET UP MANUAL

					
<p><b>SETTING UP:</b> Open the frame to 75% of full extension.</p>	<p>After fitting the roof on the frame, connect the velcro around the legs at the top of the frame.</p>	<p>Fit the centre of the roof on top of the centre pole cup and pull strings until tight.</p>	<p>Fully open the frame. grasp lower truss bars as indicated and walk backwards.</p>	<p>Engage the pin on the upper section of the frame so that it is locked in. Place a foot on the base and push the connector up into place.</p>	<p>Make sure the frame locking pins have all been engaged.</p>
					
<p>Tighten roof by attaching the roof tie down straps to the truss bars.</p>	<p>Extend legs to desired height. Ensure locking pins have engaged.</p>	<p><b>PACKING DOWN:</b> pullrings on the lower legs locking pins and retract legs.</p>	<p>Undo the roof tie down straps.</p>	<p>Pull rings on the upper roof locking pins.</p>	<p>Grasp the top truss bar and walk forward.</p>